

DTCM120-190H-AL

C-mount Bi-telecentric Lens

- Optimized for 1/2.5"~1.1" C-Mount cameras;
- Largest FOV from 26mm upto 300mm;
- Excellent resolution for high pixel cameras;
- Low distortion, good telecentricity, big aperture and big depth of field for high end application.



Optical Specifications	
Magnification (x)	0.042
Object Field of View (Φmm)	190
Working Distance (mm)	330±5
Max Sensor Size (Φmm)	8.0(1/2")
Best Aperture (F/#)	4.2
Telecentricity typical (max) (deg)	<0.1
Distortion typical (max) (%)	<0.1
MTF30 (lp/mm)	>210
Depth of Field (mm)	±248@F11
Length of I/O (mm)	750±5

Field of View (mm × mm)	
1/2.5" 9P001/31 (5.7x4.28)	135.7x101.9
1/2.3" 9J003 (6.44x4.62)	153.3x110.0
Mechanical Specifications	
Mount	C
Length (mm)	402.5
Weight (kg)	9.6
Compatible Lighting	
Telecentric LED Lighting	DTCL-190H-xW-y
	Beam Diameter 190mm

Notes:

1. Depth of Field is calculated value, this value could be used for imaging test, but to get sharp image in application, half of calculated value is suggested.
2. Length of I/O = WD + Length + Back Focal Length.

