

WWK066-110C-110

Large FOV Objective Telecentric Lens

- Object side telecentric lens, support 5Mp-20Mp area scan camera.
- High definition, low distortion, good telecentricity, especially suitable for high-precision AOI and positioning applications.
- Built-in coaxial lighting, especially suitable for inspection of wafers, glass devices.
- Quickly customization apply to different camera specifications, as well as magnification, working distance, DOF requirements.



Optical Specifications	
Magnification (x)	0.66
Working Distance (mm)	110
Max Sensor Size (Φmm)	18(1")
Best Aperture (F/#)	7
Telecentricity typical (max) (deg)	≤ 0.01
Distortion typical (max) (%)	≤ 0.02
MTF30 (lp/mm)	> 135
Depth of Field (mm)	±0.6@F7

Field of View (mm × mm)	
1"PYTHON5000(12.43x9.83)	18.8x14.9
1"IMX255(14.19x7.51)	21.5x11.4
1"IMX183(13.13x8.76)	19.9x13.3
Mechanical Specifications	
Mount	C
Length (mm)	129.8
Coaxial Light	Yes

Notes:

1. Depth of Field is calculated value, this value could be used for imaging test, but to get sharp image in application, half of calculated value is suggested.
2. Length of I/O = WD + Length + Back Focal Length.

