



## INDUSTRIAL/MACHINE VISION APPLICATIONS

# FLIR ORYX°

P/N: ORX-10GS-51S5

## **FAST AND VERSATILE**

The award winning Oryx 10GigE camera family allows systems designers to take advantage of the latest sensors by supporting transfer speeds up to 10Gbit/s enabling the capture of 5 megapixel, 8-bit images at 163 FPS. Oryx's 10GBASE-T interface is a proven and widely deployed standard that provides reliable image transfer at cable lengths over 50 meters on inexpensive CAT6A, or greater than 30 m on CAT5e. On-camera features including IEEE1588 clock synchronization and full compatibility with popular third-party software supporting GigE Vision, gives system designers the tools to quickly develop innovative solutions.

www.flir.com/products/oryx-10gige

## **FEATURES**

## HIGH RESOLUTION SENSOR ON HIGH SPEED INTERFACE

Increase throughput by capturing 12.3 MP Global Shutter images at 68 FPS

## RELIABILITY AND SIMPLICITY

10GBASE-T interface supports cables over 60m and makes multi-camera system set-up easy

#### FLEXIBILITY FOR INTEGRATORS

Develop innovative solutions quickly with GigE Vision compatibility and advanced on-camera features

## **APPLICATIONS**

SPORTS ANALYTICS AND MOTION TRACKING

**AUTOMATED OPTICAL INSPECTION** 

RESEARCH

LARGE VOLUME 3D SCANNING

BROADCAST + VR









## **SPECIFICATIONS**

SPECS	ORX-10GS-51S5M-C	ORX-10GS-51S5C-C
Resolution	2448 x 2048	
Frame Rate	162 FPS	
Megapixels	5 MP	
Chroma	Mono	Color
Sensor	Sony IMX250, CMOS, 2/3"	
Readout Method	Global shutter	
Pixel Size	3.45 μm	
Lens Mount	C-mount	
ADC	8-bit, 10-bit, and 12-bit	
Minimum Frame Rate*	1 FPS	
Gain Range*	0 to 48 dB	
Exposure Range*	17 μs to 30 s	
Acquisition Modes	Continuous, Single Frame, Multi Frame	
Partial Image Modes	Pixel binning, decimation, ROI	
Image Processing	Gamma, lookup table, and sharpness	Color correction matrix, gamma, lookup table, saturation, and sharpness
Sequencer	Up to 8 sets us	ing 2 features
Image Buffer	240 MB	
User Sets	2 user configuration sets for custom camera settings	
Flash Memory	4 MB non-volatile memory	
Opto-isolated I/O	2 input, 2 output	
Non-isolated I/O	2 bi-directional	
Serial Port	1 (over non-isolated I/O)	
Auxiliary Output	3.3 V, 120 mA maximum	
Interface	10GigE	
Power Requirements	Externally powered over GPIO (12 - 24 V)	
Power Consumption	12.3 W maximum (11.7 W nominal)	
Dimensions/Mass	60 mm x 60 mm x	x 64 mm / 386 g
Machine Vision Standard	GigE Vision	
Time Synchronization Protocol	IEEE 1588 Precision Time Protocol	
Compliance	CE, FCC, RoHS, REACH. The ECC	CN for this product is: EAR099.
Temperature	Operating: 0°C to 70°C (case) Storage: -30°C to 60°C (ambient)	
Humidity	Operating: 20% to 80% (no condensation) Storage: 30% to 95% (no condensation)	
Warranty	3 years	

<sup>\*</sup>Ranges are the same in binning and no binning modes.

### FLIR Integrated Imaging Solutions

CANADA

T: +1 866.765.0827 (toll free) T: +1 604.242.9937 F: +1 604.242.9938

E: mv-sales@flir.com

T: +1 866.765.0827 (toll free) E: mv-na-sales@flir.com

www.flir.com/mv

EUROPE

12051 Riverside Way
Richmond, BC, Canada
V6W 1K7

1: +49 7141 486817-99
F: +49 7141 488817-99
E: mv-eusales@flir.com

CHINA

T: +86 10 8215 9938 F: +86 10 8215 9936 E: mv-chinasales@flir.com

ASIA

E: mv-asiasales@flir.com

©2020 FLIR® Integrated Imaging Solutions Inc. All rights reserved. Names and marks appearing on the products herein are either registered trademarks or trademarks of FLIR® Systems, Inc. and/or its subsidiaries. Specifications are subject to change without notice.

VN: 20-0483-OEM-ORX-10GS-51S5-v2

FIND THE BEST ORYX FOR YOUR NEEDS



www.flir.com NASDAQ: FLIR

